

[Click Here to return to kesslercrane.com](#)

[My activities](#)

[Submit a request](#)

[Sign in](#)



Search



[Kessler Crane Support](#) > [Camera Sliders](#) > [Shuttle Dolly](#)

## MANUAL: Shuttle Dolly Adding Motion Quick Start Guide

[Download the Shuttle Dolly Adding Motion Quick Start Guide](#)

### RECENTLY VIEWED ARTICLES

[VIDEO: Vertical Dolly Moves with a Pocket Dolly](#)

[MANUAL: Shuttle Dolly Keeper/Grabber Quick Start](#)

[HOW-TO: Installing Shuttle Pod Keeper/Grabber Wheels](#)

[MANUAL: Shuttle Dolly Quick Start Guide](#)

### RELATED ARTICLES

[MANUAL: Shuttle Dolly Keeper/Grabber Quick Start](#)

[VIDEO: Parallax Installation on Pocket Dolly](#)

[MANUAL: Pocket Dolly](#)

[MANUAL: Shuttle Dolly Quick Start Guide](#)


[HOW-TO: Low Profile Ball Head V2 - Quick Start](#)

**SHUTTLE DOLLY®**


**ADDING MOTION AND DRAG CONTROL**




Line up the motor mount arm with the holes on the platform and mount the two knobs as shown.



Lift up the belt brackets on each end clamp.



Loosen the belt clamp and insert the belt with the teeth facing down. Tighten knob to secure.




Weave the belt through the motor mount pulleys as shown.




Pull tight on the belt. Loosen opposite belt clamp and inset the belt into the clamp with the teeth facing down. Tighten the knob to secure.



To install the motor, place the motor drive belt around pulley as shown.



Tighten the motor mount knobs to secure



Drag module can be mounted by wrapping belt around pulley as shown and tightening knobs in back to secure.



Tighten the knob clockwise to increase tension.

[Adding.Motion.pdf \(5 MB\)](#)

Was this article helpful?



0 out of 0 found this helpful

Have more questions? [Submit a request](#)

## Comments

 Powered by Zendesk